

# TPG POS Driver Help

# What drivers do I need to download?

## **Do you want to use USB and simulate a Communication Port?**

The RS-232 USB Emulation Driver allows your application to think that it is communicating with a serial port, but is actually using the USB link to communicate with the printer. (The RS-232 Emulation USB Driver maps a virtual communication port thru USB)

**Note:** Please refer to the readme.txt files included in the download for installation information

Please make sure that, prior to ordering, you have the interface that you need for your POS system. The most important is to see if you require RS-232 Emulation Boot firmware.

For best results determine which printer you need. Contact your Point of Sale software application provider to see if your system requires Direct USB or RS-232 Emulation.

## **Are you using TPG OPOS WIN 98/2K/XP?**

If you are using an application that is written to interface with the OPOS "Ole Point of Sale" standard, then the TPG OPOS Driver will allow you to communicate with the TPG Printers. The TPG OPOS Driver provides the mechanisms to print on the receipt station, the slip station, read MICR, and lift check images on the Microsoft Windows Operating Systems. (The OPOS Driver can communicate using RS-232 or USB. If you use USB, download the TPG Native USB Driver and make sure the TPG Printer is configured for Native USB)

**Note:** Please refer to the OPOS User Guide included in the OPOS Driver download for setup information

OPOS Driver for Windows 98/2K/XP (using RS-232 or Native USB)

## **Are you using JPOS Linux/WIN 98/2K/XP?**

The JPOS "Java Point of Sale" Driver provides the same solution as the OPOS Driver, but is written in JAVA so it can be distributed across both Windows and Linux Operating Systems.

## **Do you want to print to a Windows Application?**

The TPG Mini Drivers allow you to print to TPG printers using the Microsoft Windows Print System. After downloading the appropriate mini drivers, you would use the MS Windows "Add Printer" wizard to install the mini driver(s).

**Note:** For the TPG Hybrid (slip & receipt) printers you will need to download both the slip and the receipt mini drivers. (The mini drivers can communicate as RS-232, USB or ethernet. If you use the USB communication, the TPG printer must be configured to Printer Class USB).

For A758 use A794 receipt & A758 slip

For A760 use A795 receipt & A760 slip

Please refer to the readme.txt files included in the download for installation information

**Transaction Printer Group – Headquarters**

25 Tri-State International, Suite 200, Lincolnshire, IL 60069  
Tel: 847 383 7900 Fax: 847 383 7949 [www.TPGprinters.com](http://www.TPGprinters.com)

**Sales Toll Free** – 800 732 8950

**Technical Support** – 877 209 0156

© 2006 Transaction Printer Group (TPG) a subsidiary of ATSI Holdings, Inc. All Rights Reserved. Patents pending. All trademarks or registered trademarks are the property of their respective owners. Product specifications are subject to change in order for TPG to continue to meet the needs of the market. Printed in U.S.A.